


TL114044  
 MACK LE / MR  
 FACTORY WIRING FOR TELMA  
 LAST UPDATE 23-MAR-04

For Mack LE:  
relays are  
located in the  
electrical  
compartment  
below drivers  
seat under the  
black cover  
farthest  
forward on the  
back wall of  
compartment

For Mack MR:  
relays are  
located in the  
center console



ABS fault relay  
not used on MR

last  
update  
28-apr-05