

TL134072 AIR BRAKE WIRING DIAGRAM WITH TRCM2 AND J1939 CAN 22oct20jh

J1939 CAN control features:
TRCM active outputs turn off
under the following conditions.
1) during ABS event
(with progressive reactivation)
2) Speed below 2 mph
3) Throttle position greater than 1%

Note: For Telma activation when accelerator is released
1) connect org/blk wire (TRCM gray pin 1) at hand control plug to ground for 25% activation when accelerator is released
2) connect org/blk and blu/red wire (TRCM gray pins 1 and 2) at hand control plug to ground for 50% activation when accelerator is released.
Caution: Connect with on/off switch to turn off this function under slippery conditions

